

# Remove Room Temperature Powder Coat Remover

---

Michigan  
United States

Remove Room Temperature Powder Coat Remover [Remove.com.co](http://Remove.com.co) | Room Temperature | PowderCoating Remover

Remove | "Room Temperature" Powder Coat Remover to Remove Powder Coating from Hooks, Racks and Powder Coating Rework: "Remove" Powder Coat Remover | Remove Powder Coating from Hooks, Racks & Powder Coat Rework at Room Temperature. Remove is Eco-friendly, Non-regulated by US DOT, Operator friendly, Non-Caustic, Non-Acid and Low Odor Powder Coating Remover, Available in a Liquid or Gel. Remove 9000-Liquid Powder Coat Remover T E C H N I C A L D A T A S H E E T Directions: Remove 9000 Dissolves Powder Coat in 15 minutes to 1-2

hours at Room Temperature, used in an immersion tank, drum or pail. It's Aluminum & All Metal Safe. Formulated to Clean Powder Coating from Hooks, Racks and Coating Rework at Room Temperature . Strip time will vary depending on type of coating and coating film build. Mechanical Agitation is not required, however will accelerate stripping. Air agitation is not recommended: Air-(Oxygen will reduce solution life). Use No-Water with Remove 9000. Rinse parts with water after stripping. Available in

1-Gallon Bottles, 5-Gallon Pails and 55-gallon drums at:

[mileschemicalsolutions.com/secure\\_order\\_form.htm](http://mileschemicalsolutions.com/secure_order_form.htm) Begin to reclaim coating rework and clean hooks in-plant today and save!

[Place\\_Secure\\_Order\\_Here](#) Remove 9001-Gel Powder Coat Remover T E C H N I C A L

D A T A S H E E T Directions: Apply Remove 9001-Gel to parts with a natural bristle brush, lambs wool roller or use in an immersion tank, drum or pail. Remove 9001-Gel Dissolves Powder Coat in 15 minutes to 1-2 hours at Room Temperature.

It's Aluminum & All Metal Safe. Formulated to Clean Powder Coating from Hooks, Racks and Coating Rework at Room Temperature . Strip time will vary depending on type of coating and coating film build. Mechanical Agitation is not required, however will accelerate stripping. Air agitation is not recommended: Air-(Oxygen will reduce

solution life). Use No-Water with Remove 9001. Rinse parts with water after stripping. Begin to reclaim coating rework and clean hooks in-plant today and save!

[Place\\_Secure\\_Order\\_Here](#)

[Visit Website](#)

[Send Message](#)

[Email Friend](#)